Westinghouse

USER'S MANUAL

MANUEL DE L'UTILISATEUR

MANUAL DEL USUARIO

CW26S3CW

1	IMPORTANT INFORMATION		2
2	HOW TO INSTALL THE STAND		4
3	PREFACE		5
4	SAFETY PRECAUTIONS		5
5	CONTENTS		7
6	FRONT/BACK CONNECTIONS OF LCD TV		8
7	TV INSTALLATION	Power Cord Connection	9
		Antenna Connection	9
		AV Connection	10
		YPbPr(component) Connection	10
		VGA(PC) Connection	11
		Service Port Function	11
		HDMI Connection	12
8	REMOTE CONTROL	Remote control instructions in TV mode	13
		Remote control setup	14
9	MENU OPERATION	SETUP WIZARD	15
		Operating the Menu	17
		PICTURE Menu	18
		AUDIO Menu	19
		TIME Menu	19
		SETUP Menu	20
		LOCK Menu	22
		CHANNEL Menu	24
10	TROUBLESHOOTING		26
11	SPECIFICATIONS		27

English

The lightning flash with arrowhead symbol, within an equilateral triangle, is intended to alert the user to the presence of un-insulated dangerous voltage within the products enclosure that may be of sufficient magnitude to constitute a risk of electric to persons.

The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instruction the literature accompanying the appliance.

CAUTION: USE OF ANY CONTROLS, ADJUSTMENTS, OR PROCEDURES OTHER THAN THOSE SPECIFIED HEREIN MAY RESULT IN HAZARDOUS RADIATION EXPOSURE.

CAUTION: These servicing instructions are for use by qualified service personnel only. To reduce the risk of electric shock, do not perform any servicing other than that contained in the operating instructions unless you are qualified to do so.
Refer to service manual for servicing instructions.

Important Safety Instructions

Note:

1.Read these instructions.
2.Keep these instructions.
3.Heed all warnings.
4.Follow all instructions.
5.Do not use near water.
6.Clean only with dry cloth.
7.Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
8.Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
9.Do not defeat the safety purpose of the polarized or grounding-type plug. A polarized plug has two blades with one wider than the other. A grounding type plug has two blades and a third grounding prong. The wide blade or the third prong are provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.

10.Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.

11.Only use attachments / accessories specified by the manufacturer.

12.Use only with the cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the apparatus. When a cart is used, use caution when moving the cart / apparatus combination to avoid injury from tip-over.

13.Unplug this apparatus during lightning storms or when unused for long periods of time.

14.Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.

15.Apparatus shall not be exposed to dripping or splashing and that no objects filled with liquids, such as vases, shall be placed on the apparatus.

16.WARNING:To reduce the risk of fire or electric shock, do not expose this apparatus to rain or moisture.

17.Mains plug or appliance coupler is used as the disconnect device, shall be readily operable.

18.The apparatus shall be connected to a MAINS socket outlet with a protective earthing connection.

19.WARNING:The batteries shall not be exposed to excessive heat such as sunshine, fire or the like.

20.The ON-MODE Power under Home Mode should be less than 65.0W.

21.The Sleep Mode power should be less than 1.0W.

22. ⧈ This equipment is a Class II or double insulated electrical appliance. It has been designed in such a way that it does not require a safety connection to electrical earth.

23. (Hg) Lamp(s) inside this product contain mercury and must be recycled or disposed of according to local, state or federal laws.

This Westinghouse product has earned the Energy Star® for meeting U.S. Federal energy efficiency guidelines as set by the Department of Energy and Environmental Protection agency. The Energy Star® program exists to provide energy saving guidelines and help promote energy efficient products and practices. Changes to certain features, settings and functions of this TV can change and/or increase its power consumption. Depending on how settings are changed, power consumption may exceed the limits required for Energy Star® qualification. This Westinghouse TV will operate at optimal energy efficiency in “Home” mode.

How to install the stand!

Follow instructions below to install the base of the TV, reverse the instructions to remove the base.

English

①



The base stand

②



Main Unit

③



④



Screw(TP4X16A-HO, 6PCS)





3. PREFACE

Thank you for buying this TV! Please read this manual thoroughly before operating the TV. Make sure the TV was not damaged in transit. Should the TV be damaged, do not install it and contact your dealer. Check that you have all the accessories according to the model.

4. SAFETY PRECAUTIONS

Put the TV on a stable surface.

Do not place any material on the TV.



Do not use the TV with fixtures other than those provided or suggested by the manufacturer.

Do not block or cover the ventilation openings on the TV.
If you have a wall mount, check that it is steady.

Power cord and cables must be properly routed and protected to prevent people from stepping on them and causing the TV to fall.

Keep the TV dry and away from humidity.



Keep the TV away from heat sources.

Unplug the TV before cleaning it. Do not use solvent or liquid to clean the TV.

Only clean the TV with a soft and dry cloth.



In case of troubleshooting, do not use spare parts other than those suggested by the manufacturer. Using inadequate spare parts can lead to electric shocks, short-circuits, fire or other incidents.

Unplug the TV during lightning storms or when unused for long periods of time.

5. CONTENTS



LCD TV SET

Remote Control



USER'S MANUAL



AAA Batteries

Warranty Card

Quick Connect Guide

English

6. FRONT/BACK CONNECTIONS OF LCD TV

Front View



1. Press “⏻” button to turn the TV on or off.
2. Press “INPUT” to select the input source.
3. Press “MENU” to bring up the main menu on the screen.
4. Press “CH+” or “CH-” to scan through channels.
5. Press “VOL+” or “VOL-” to increase or decrease the volume.
6. REMOTE SENSOR: infrared sensor for the remote control.
7. POWER INDICATOR: Blue when TV is powered on. Red when TV is powered off.

Back View and Control Connections



1. USB SERVICE: USB Port for Factory Use Only.
2. HDMI1/HDMI2/HDMI3: Connect the HDMI output jack of DVD.
3. PC AUDIO: Connect the Audio output jack of PC.
4. VGA(PC): Connect the PC-RGB output jack of PC.
5. RF IN: Connect the antenna.
6. COAX out: Connect the COAX receiver.
7. YPbPr: Connect the YPbPr output.
8. AV: Connect the Video output.
9. L/R: For AUDIO out.

7. TV INSTALLATION

Power Cord Connection

- Connect the power cord correctly as shown.



Antenna Connection

To ensure good picture and sound, TV antenna system needs to be installed. The antenna system as shown can be sourced from TV equipment shops, which will provide service for correct installation and connection. After installation, insert the 75-ohm antenna plug into the antenna jack as shown.



English

AV Connection

Connect the VIDEO and AUDIO output jack of the DVD or VCR to the VIDEO jacks on the set using the RCA cable. Match the jack colors: Video is yellow, Audio left is white, and Audio right is red.
Select the AV input source using the SOURCE button on the remote control.

TV Back



YPbPr (Component) Connection

Connect the YPbPr output of the DVD or VCR to the YPbPr input on the set. The picture quality is improved; compared to connecting a regular VCR to the video input. Connect the Audio output of the DVD or VCR to the Audio input jacks on the set using the RCA cable.
Match the jacks colors :Y is green,Pb is blue,Pr is red,Audio left is white and Audio right is red.
Select component input source using the SOURCE button on the remote control.



TV Back

YPbPr cable

AUDIO cable



VGA(PC) Connection

Connect the RGB output of the PC to the VGA(PC) jack on the set. Connect the AUDIO output of The PC to the PC AUDIO jack on the set. Select the VGA input source with using SOURCE button on the remote control.

TV Back



Service Port Function

Service port: (For factory uses only.)

TV Back



English

HDMI Connection

HDMI plug which replaces the HDMI connection allows transfer of all audio/video control signals through one cable only. These signals are transferred in digital.



English

8. REMOTE CONTROL

Remote control instructions in TV mode

POWER
Turn the LCD TV ON or OFF.

MUTE
Press to mute the sound. Press again or press VOL+ to un-mute the TV.

NUMBER BUTTONS
Press 0-9 to directly change the TV channel.

—
Press this button to enter a program number for multiple program channel such as 2-1,etc.

Return to the previous channel viewed.

P.MODE
Select the picture mode.

S.MODE
Select the sound mode.

MTS
Press to adjust between available audio channel.

SLEEP
Set the sleep timer.

SOURCE
Press SOURCE to display the OSD input source, press ▲▼to select an input source, and then press OK to confirm.

VOL+/VOL-
Press to increase / decrease the sound level.

CH+/CH-
Press to scan through channels.

INFO
Display information about the current channel.Press again to release it.

FREEZE
Press to freeze the current screen button,press again to release it.

CH.LIST
Press to display the TV program list.

AUTO
Auto adjust（only use in the VGA source）.

ASPECT
Press to select Aspect Ratio.

THUMBSTICK(▲/ ▼/◄ / ►/ OK)
Allows you to navigate the on-screen menus and adjust the system settings to your preference.

MENU
Brings up the main TV menu to the screen.

EXIT
Exit the main TV menu to the screen.

CC
Press to display the closed caption.

V-CHIP
Setting up parental list.

ADD/ERASE
Add or delete favorite channels.

FAV
Press to display the TV favourite program list.

Remote control setup

1. Open the cover.
2. Uses AAA size batteries. When inserting the batteries, make sure correct polarities “+”and “-” marks on the batteries line up correctly with compartment markings.
3. Replace the battery cover.

To prevent battery leakage which may result in bodily injury or damage to the remote:

1. Install all batteries correctly, and as marked on the remote control.
2. Do not mix batteries:(OLD and NEW or CARBON and ALKALINE, etc)
   Remove batteries when the remote is not used for a long period of time.



9.Menu Operation

SETUP WIZARD

Select Language


Select Language
Welcome to the Westinghouse HDTV Setup Wizard.
Follow this guide to help setup your HDTV for Scanning channels or accessing your external devices for cable,satellite,Blu-ray,DVD,and gaming.
use the Up and Down arrows on your remote control to select the language to use for menus and message screens.
English
Français
Español
:Select
Enter:Next

Time Zone



Power on Mode


Power on Mode
Use the Up and Down arrows on your remote control to select power on mode.
Home optimizes the video setting for Energy Star qualification.
Home
Retail
Go Back
:Select
Enter:Next


Power on Mode
Use the Up and Down arrows on your remote control to select power on mode.
Showroom optimizes the video setting for use on a retail showroom floor or demo environment.
Home picture mode is the mode in which the product qualfies for ENERGY STAR
Home
Retail
Go Back
:Select
Enter:Next

Setup Wizard


Let's Get Connected...
Click Here To Connect A Cable Box or Satellite Box
Click here to connect a Game,Blu-Ray,DVD,or other player
Click here to scan channels from the Antenna or coaxial cable Input
Go Back
:Select
Enter:Next


Cable or Satellite Source input
Use the Left/Right arrows on your remote control to select the type of connection are you using to connect the set top box?
For optimal vide quality,we recommend HDMI or Component (refer to Quick Connect Guide or User Manual to help you determine what connection you are using).
HDMI
Component
Other
Antenna
Go Back
:Select
Enter:Next


Let's Get Connected...
Click Here To Connect A Cable Box or Satellite Box
Click here to connect a Game,Blu-Ray,DVD,or other player
Click here to scan channels from the Antenna or coaxial cable Input
Go Back
:Select
Enter:Next

English


Channel Scan
Let's Get Connected...
Click Here To Connect A Cable Box or Satellite Box
Click here to connect a Game,Blu-Ray,DVD,or other player
Click here to scan channels from the Antenna or coaxial cable Input
Go Back
:Select
Enter:Next
Scan Channels from the Antenna or coaxial cable input
Use the Up and Down arrows on your remote control to select the channel scan type.
Antenna[ATSC]
Cable
Go Back
:Select
Enter:Next
Antena
A
Cable
Scanning channels
RF CH : 24
Found : 0
Menu:Quit
No Channels Found
The Setup Wizard did not find any channels.
Check your antenna or cable connection.
You may haveselected an improper RF Input Source.
Check your setup and try again.
Repeat
:Select
Enter: Next
If channels can not be found, this frame will be displayed automatically
A
Antenna[ATSC] Channel Access
Antenna users need a Channel Access Code in order to perform a channel scan and receive broadcast signals.
Contact Westinghouse's Channel Access Service by:
Web: www.westinghousedigital.com/support;
select Channel Access and enter Access Info.
Text Message: Text Tuner to 95495
Phone:1-800-701-0680 follow instructions
Select Next to obtain the Access code.
Go Back
Next
:Select
Enter:Next
Antenna[ATSC] Channel Access Information
To access channel scan you will need the following Access Information:
Model: CW26S3CW
Serial No: 0000H00000000
Channel Scan Type: ATSC
Provide these items to Westinghouse's Channel Access Service by web, text, or phone to obtain an Access Code, then select Next to input access code.
Go Back
Next
:Select
Enter:Next
Enter Channel Access Code
Using your remote control to enter the 5 digit access code provided by the channel access service.
Go Back
Next
0-9:Key in password
Enter:Next
Right
Error
Scanning channels
RF CH : 24
Found : 0
Menu:Quit
ERROR: Access Code Incorrect
Check the access code provide by the Channel Access Service, then select Go Back to enter the access code again.
If the Channel Access continues to fail contact Westinghouse Digital customer service at 1-800-701-0680 for further assistance.
Go Back
:Select
Enter:Next

Operating the Menu

1.Press the POWER button to turn the LCD TV on.

2.Press the MENU button on the remote control, the on-screen menu will appear on the screen.

3.Use the LEFT and RIGHT buttons to select your main menu option.

PICTURE MENU:

Allows you to make adjustments to your picture settings.(select TV source for example)



AUDIO MENU:

Allows you to customize the audio options and effects.(select TV source for example)



TIME MENU:

Allows you to set up a variety of timer options. (Select TV source for example)

SETUP MENU:

Allows you to set up a variety of setup options. (Select TV source for example)



LOCK MENU:

Allows you to set up a variety of lock options. (Select TV source for example)

CHANNEL MENU:

Allows you to search channels and set up a variety of channel options. (Select TV source for example)

4.Use the UP/DOWN buttons to select an option of the sub-menu, and press the RIGHT button.
While in adjustment mode, use the LEFT/RIGHT button to change the value of the item.
5.Press the MENU button to exit the menu.

Note:
Only when you input the suitable signal, the relevant items can be activated.

1.Press the POWER button to turn the LCD TV on.
2.Press the MENU button on the remote control, the on-screen menu will appear on the screen.
3.Use the LEFT and RIGHT buttons to select your main menu option.

PICTURE Menu

Select TV source for example.

1. Press the MENU button on the remote control to display the Main menu, and use the LEFT and RIGHT buttons to select the PICTURE.
2. Use the UP and DOWN buttons to highlight an individual PICTURE option, use the LEFT and RIGHT buttons to change the setting, and press the MENU to exit the menu.



The PICTURE menu includes the following options :

Picture Mode
Cycles among picture display modes: Standard, Dynamic, Movie, User.
Contrast
Controls the difference between the brightest and darkest regions of the picture.
Brightness
Controls the overall brightness of the picture
Color
Control the color.
Sharpness
Increase this setting to see crisp edges in the picture; decrease it for soft edges .
Color Temp.
Cycles among color temp: Neutral,Warm,Cool.

AUDIO Menu

Select TV source for example.



1. Press the MENU button on the remote control to display the Main menu, and use the LEFT and RIGHT buttons to select the AUDIO.
2. Use the UP and DOWN buttons to highlight an individual AUDIO option, use the LEFT and RIGHT buttons to change the setting, and press the MENU to exit the menu.

The AUDIO menu includes the following options :

Sound Mode

Allows you to select among: User, Standard, Music, Movie.

Bass

Controls the relative intensity of lower pitched sounds.

Treble

Controls the relative intensity of higher pitched sounds

Balance

To adjust the balance of the left and right sound track, or turn off the volume of the left and right sound track.

SPDIF Audio Type

Allows you to select between: PCM and RAW.

Audio Language

Allows you to select audio languages among: English, Français and Español.

TIME Menu

Select TV source for example.

1. Press the MENU button on the remote control to display the Main menu, and use the UP and DOWN buttons to select the TIME.
2. Use the UP and DOWN buttons to highlight an individual TIME option, use the LEFT and RIGHT buttons to change the setting, and press the MENU button to exit.

The TIME menu includes the following options :

Sleep Timer

Allows you to set up the sleep timer among: 5Min, 10Min, 15Min, 30Min, 45Min, 60Min, 90Min, 120Min, 180Min, 240Min and Off.

Time Zone

Allows you to set up the time zone ：Pacific, Alaska, Hawaii, Eastern, Central and Mountain.

Daylight Saving Time

Allows you to set up the daylight saving between On or Off.

SETUP Menu

Select TV source for example.



1. Press the MENU button on the remote control to display the Main menu, and use the LEFT or RIGHT button to select the SETUP.
2. Use the UP and DOWN buttons to highlight an individual SETUP option, use the LEFT and RIGHT buttons to change the setting, and press the MENU button to exit.

The SETUP menu includes the following options:

Menu Language

Allows you to select menu language among: English, Français and Español.

Zoom Mode

Allows you to select the zoom mode among: Standard, Fill, Overscan.

Noise Reduction

Allows you to select the noise reduction mode among: Strong, Off, Weak, Medium.

PC Setup (In VGA Mode only)

Input PC signal first, then press SOURCE button to select VGA mode, press RIGHT button to confirm.



H-Position	Allow you to use LEFT and RIGHT button to adjust the H Position.
V-Position	Allow you to use LEFT and RIGHT button to adjust the V Position.
Clock	Allow you to prolong the image.
Phase	Allow you to adjust the definition.
Auto	Select “Auto”and press RIGHT, the unit will automatically adjust all items to achieve a best effect.

Closed Caption

Use Down button to highlight the Closed Caption item, then press RIGHT button to enter into the following menu.

CC Mode

Allows you to select the CC Mode among: On, Off and CC on Mute.

Basic Selection

Allows you to select the basic selection among: CC1, CC2,CC3, CC4, Text1, Text2, Text3 and Text4.

Advanced Selection

Allows you to select the advanced selection among: Service1, Service2, Service3, Service4, Service 5 and Service 6.

Option

Use Down button to highlight the “Option”item, then press RIGHT button to enter into the following menu.



Use UP and DOWN buttons to highlight the desired item, and use LEFT and RIGHT buttons to select.

DLC

Dynamic luminance control On or Off.

Restore Default

Restores all settings to factory settings.

English

LOCK Menu

Select TV source for example.

1. Press the MENU button on the remote control to display the Main menu, and use the LEFT and RIGHT buttons to select the LOCK
2. Use the DOWN button to highlight the “Enter Password”item, use the numeric keys to input 4-digital password, then the screen will display the junior menu. After settings, press menu button to exit.

NOTE: The factory password is 0000.



The LOCK menu includes the following options :

Change Password

Use DOWN button to select the “Change Password” item, then press RIGHT button to enter into the following menu. Input the new 4-digital password and input it again to confirm.

System Lock

Allows you to turn on or off the system lock.
If you turn off the system lock, then the following items (US, Canada and Reset RRT) will unable to use.

US

Use Down button to highlight the “US”item, then press RIGHT button to enter into the following menu.

TV

Use Down button to highlight the “TV”item, then press RIGHT button to enter into the following menu.



Use UP and DOWN buttons to select the desired rating and press OK button to block or unblock rating.

MPAA

The Movie rating (MPAA) is used for original movies rated by the Motion Picture Association of America (MPAA) as broadcasted on cable TV and not edited for television.

Use RIGHT and LEFT button to select N/A, G, PG, PG-13, R, NC-17 or X.

RATING	DESCRIPTION
G	General Audiences. Movie is appropriate for all ages.
PG	Parental Guidance Suggested. May contain material not suited for younger viewers.
PG-13	Contains content that may not be appropriate for viewers under the age of 13.
R	Restricted. Contains adult content, no one under 17 admitted without parent.
NC-17	No one 17 and under admitted.
X	Adults only.

Canada

Use Down button to highlight the “Canada” item, then press RIGHT button to enter into the following menu.

Canada English

Use LEFT and RIGHT buttons to select among: E, C, C8+, G, PG, 14+ and 18+

Canada French

Use LEFT and RIGHT buttons to select among: E, G, 8ans+,13ans+, 16ans+ and 18ans+

Reset RRT

Allows you to reset the RRT setting.

English

CHANNEL Menu

Select TV source.

1. Press the MENU button on the remote control to display the Main menu, and use the LEFT and RIGHT buttons to select the CHANNEL.
2. Use the UP and DOWN buttons to highlight an individual CHANNEL option, use the LEFT and RIGHT buttons to change the setting, and press the MENU button to exit.



The CHANNEL menu includes the following options :

Air/Cable/QAM
Allows you to select antenna between Air、Cable and QAM.

Use Down button to highlight the “Auto Scan” item, then press RIGHT button to enter into the following menu.

If you select “Air”as input signal in Antenna item, you can press RIGHT button to search the channels automatically.

The receivable channels will be stored automatically.
When searching channels, press MENU to stop.

If you select “Cable”as input signal in Antenna item, allows you to select Cable System among: AUTO, STD, IRC and HRC.
Use DOWN button to highlight the “Start to Scan”, then press RIGHT button to search the channels automatically.
The receivable channels will be stored automatically.
When searching channels, press MENU to stop.

If you select "QAM" as input signal in Antenna, these frames will be displayed automatically (but these frames will be displayed only in the first scan).


QAM Cable Channel Access
Cable QAM users need a Channel Access Code in order to perform a channel scan and receive broadcast signals.
Contact westinghouse's Channel Access Service by:
Web: www.westinghousedigital.com/support; select Channel Access and enter Access Info.
Text Message: Text Tuner to 95495
Phone:1-800-701-0680 follow instructions
Select Next to obtain the Access code.
Go Back
Next
:Select
Enter:Next
QAM Cable Channel Access Information
To access channel scan you will need the following Access Information:
Model: CW26S3CW
Serial No: 0000H00000000
Channel Scan Type: QAM
Provide these items to Westinghouse's Channel Access Service by web, text, or phone to obtain an Access Code, then select Next to input access code.
Go Back
Next
:Select
Enter:Next


Enter Channel Access Code
Using your remote control to enter the 5 digit access code provided by the channel access service.
Go Back
Next
0-9:Key in password
Enter:Next
Error
ERROR: Access Code Incorrect
Check the access code provide by the Channel Access Service, then select Go Back to enter the access code again.
If the Channel Access continues to fail contact Westinghouse Digital customer service at 1-800-701-0680 for further assistance.
Go Back
:Select
Enter:Next
Right
Scanning channels
RF CH : 24
Found : 0
Menu:Quit
No Channels Found
The Setup Wizard did not findany channels.
Check yourantenna or cable connection.
You may haveselected an improper RF Input Source.
Check yoursetup and try again.
Repeat
:Select
Enter: Next

If channels can not be found, this frame will be displayed automatically

Favorite

Allows you to add these channels which you desired as the favorite channels.

Use UP or DOWN button to highlight the “Favorite”item, then press RIGHT button to enter into the following menu.

Use UP and DOWN button to highlight the desired item, then press OK button to add or remove the highlighted channel as favorite.

Show / Hide

Allows you to show or hide the channels.

Use UP or DOWN button to highlight the “Show / Hide” item, then press RIGHT button to enter into the following menu.

Use UP and DOWN button to highlight the desired item, then press OK button to show or hide the highlighted channel.

Channel No.

Display the number of current channel.

Channel Label

Display the lable of current channel.

DTV Signal

Display the quality of current DTV Signal.

10. Troubleshooting

Please check if you can solve problems by troubleshooting yourself.

Troubleshooting	Control
No signal	Please check that all cables are correctly plugged in.
No color shades	Adjust the contrast, the color and the brightness.
Stain on the screen	May be the result from a lighting signal from car, motor, neon light and other electrical devices or appliances.
Double or multiple display image	May be the result of an electrical wave disturb from other TV, Computer and Game machine or Radio.
Snow on the screen	The cables of the antenna are not correctly plugged in.
The remote control does not work	Please check the batteries order and alignment. Check that the IR of the remote control is not hidden by something.
"Zip" made noise on TV cover	Even if the display image is correct, the noise may come from an unsteady fixation of the panel.
No sound	Make sure that you have not press the MUTE button of the remote control.

11. SPECIFICATIONS

This manual is only for your reference, any change to the design and specification will not be advised.

Screen Size		26 Inch
Display Type		TFT LCD
Resolution(Pixel)		1366 X 768
Aspect Ratio		16:9
Power Supply		AC100-240V 50/60Hz
Power Consumption		70W
TV System		ATSC/NTSC
Video Input Format		PAL/NTSC
Audio Output Power		L / R 2X8W
SUPPORT	ANTENNA	YES
	AV-IN	YES
	YPbPr - IN	YES
	HDMI - IN	YES
	VGA(PC) - IN	YES
	VGA(PC) AUDIO - IN	YES
	SCART - IN	--
	SCART - OUT	--
	HEADPHONE - OUT	--
	S-VIDEO - IN	--
	COAXIAL - OUT	YES
	COMMON INTERFACE	--
	USB	Service Port Only
	IPOD	--
DVD	Disc Physical Format	--
	DVDVideoOutputFormat	--
Dimensions	Inc Stand (LxWxHmm)	653x200x461mm
	Exc Sand (LxWxHmm)	653x104x423mm
Weight	Net (Kgs)	6.7
	Gross (Kgs)	8.2